

## Humidity Indicating Cards (H.I.C.)

Desiccare, Inc. manufactures a full line of Humidity Indicating Cards (H.I.C.) which allows a low cost method of indicating humidity conditions for various types of applications including MIL Spec (MIL-I-8835) applications. Printed on a small paper with moisture sensitive spots that turn from blue to pink to indicate humidity levels. The 30%, 40%, 50% H.I.C. complies with the MS20003-2 and the 5%, 10%, 15% complies with JEDEC Standard 033 and the 5%, 10%, - 60% complies with JDEC Standard 033B. They are available in many configurations and custom cards with custom printing are available for any applications.

Desiccare's Humidity Indicating Cards are the most accurate cards available in the market today. They are often used in conjunction with a desiccant and a moisture barrier bag when shipping electronic components.

### Available cards:

1. 8%
2. 5%, 10%, 15%
3. 10%, 20%, 30%
4. 10%, 20%, 30%, 40%
5. 20%, 30%, 40%
6. 30%, 40%, 50%
7. 10%, 20%, 30%, 40% 50%, 60%
8. 5%, 10%, 20%, 30%, 40%, 50%, 60%

Custom cards with custom printing  
are available upon request.



### Benefits:

- Indicate humidity conditions in various types of barrier packaging
- Often used in conjunction with a desiccant
- Allow instant visual verification of product integrity
- Approved for MIL - I - 8835 applications
- Low cost
- Spots turn from blue to pink to indicate humidity levels

# Humidity Indicating Cards (H.I.C.)

*Protect your products  
quality & brand!*

Part Number	Type	Dimensions INCHES (h x w)	Qty	Packaged Can	Weight Container (lbs.)	Weight Carton (lbs.)
04BT14C11	8%	2 x 1.5	500	Quart	1	51
04BY14C10	5%-15%	3 x 2	125	Pint	0.5	30
04BU14C10	10%-30%	2.75 X 1.5	125	Pint	0.5	30
04BZ14C10	20%-40%	3 x 2	125	Pint	0.5	30
04BV14C10	30%-50%	3 x 2	125	Pint	0.5	30
04BW14C10	10%-40%	3.375 x 1.5	100	Pint	0.44	26
04BX14C11	10%-60%	4.5 x 1.5	200	Quart	0.86	50
04CL14C10*	5%-10%-60%	3 x 2	125	Pint	0.5	30

**\*Meets JEDEC 033B MIL SPECS**



Container:	Dimensions:
Pint Can	3.25" dia x 3.875"
Quart Can	4.25" dia x 4.75"
Pint Carton	17.25" x 17.25" x 8.25"
Quart Carton	22.5" x 22.5" x 10.5"



**DESICCARE, INC.™**  
desiccare.com

3400 Pomona Blvd., Pomona, CA 91768

Tel: 800.446.6650 Fax: 909.444.9045

E-mail: insidesales@desiccare.com